

Air Handler **BESTAIR** **Honeywell Home** **Honeywell**
Furnace Air Cleaner OEM
Replacement Filters

Available in styles that fit most whole house filter cabinets in residential applications. Meet or exceed the operating efficiency of OEM filters. 4E438 requires the original manufacturer's spacers and dividers.

6C529



4E438



| Nominal Filter Size | OEM Replacement For | Brand | Pkg. Qty. | Mfr. Model | Item No. |
|---------------------|---|--|-------------|------------------|------------|
| MERV 8 | | | | | |
| 16x20x3 | Honeywell FC35A1035 | Air Handler | 2 | 36PR96 | 36PR96 |
| | Honeywell CF200A1620, FC100A1003, FC200E1003, POPUP1620 | Bestair Pro | 2 | 5-1620-8-2 | 35N232 |
| 16x20x5 | Honeywell F100F1004 | Air Handler | 2 | 36PR99 | 36PR99 |
| | Honeywell FC100A1029 | Air Handler | 1 | 2EKL2 | 2EKL2 |
| | Honeywell FC200E1003 | Air Handler | 2 | 36PT05 | 36PT05 |
| | Honeywell FC200E1003 | Air Handler | 2 | 36PT16 | 36PT16 |
| 16x25x3 | Trion Air Bear 255649-101 | Air Handler | 2 | 36PT11 | 36PT11 |
| | Trion Air Bear 259112-101, 255649-101 | Bestair Pro | 2 | AB-31625-8-2 | 35N230 |
| 16x25x5 | Honeywell CF100A1009 | Air Handler | 1 | 2EKL3 | 2EKL3 |
| | Honeywell CF100A1009, CF100A1041, CF200A1008, FC100A1029, FC200E1029, POPUP1625, CF100A1041, 203719, F35/35R FC35A1001, F100/150 FC100A1026/1029, F200 FC200E1029, 203719 | Bestair Pro | 2 | 5-1625-8-2 | 35N233 |
| | Honeywell CF200A1008 | Air Handler | 2 | 36PT15 | 36PT15 |
| | Honeywell FC35A1001 | Air Handler | 2 | 36PT06 | 36PT06 |
| | Trion Air Bear 255649-105, General Mac 4511 | Air Handler | 2 | 36PT01 | 36PT01 |
| | Aprilaire 401 | Air Handler | 1 | 2EKL5 | 2EKL5 |
| 16x27x6 | Aprilaire 401 | Air Handler | 2 | 36PT18 | 36PT18 |
| | Honeywell CF200A1024, FC100A1011, FC200E1011, POPUP2020 | Bestair Pro | 2 | 5-2020-8-2 | 35N231 |
| 20x20x5 | Honeywell EXPXXFIL0016 | Air Handler | 2 | 36PT02 | 36PT02 |
| | Honeywell F100A1037 | Air Handler | 1 | 2EKL4 | 2EKL4 |
| | Honeywell F200A1024 | Air Handler | 2 | 36PT13 | 36PT13 |
| | Honeywell FC35A1043 | Air Handler | 2 | 36PT07 | 36PT07 |
| 20x25x5 | Honeywell 203720, F35/35R FC35A1027, F100/150 FC100A1037, F200 FC200E1037, CF100A1025, CF100A1058, FC100A1037, FC200E1037, POPUP2025 | Bestair Pro | 2 | 5-2025-8-2 | 35N234 |
| | Honeywell FC100A1037 | Air Handler | 2 | 36PT04 | 36PT04 |
| | Honeywell FC35A1050 | Air Handler | 2 | 36PT08 | 36PT08 |
| | Trion Air Bear 455602-025 | Air Handler | 1 | 6C529 | 6C529 |
| | Trion Air Bear 455602-025 | Air Handler | 2 | 36PT12 | 36PT12 |
| | Trion Air Bear Cub, Lennox, GeneralAire, Skuttle, Source 1/York, Braeburn 259112-102, 255649-102 | Bestair Pro | 2 | AB-52025-8-2 | 35N229 |
| 20x25x6 | Aprilaire 201 | Air Handler | 1 | 4E438 | 4E438 |
| | Aprilaire 201 | Air Handler | 2 | 36PT09 | 36PT09 |
| | Aprilaire 201 | Air Handler | 2 | 36PT17 | 36PT17 |
| MERV 10 | | | | | |
| 16x25x4 | Honeywell 203719, FC35A1001 | Honeywell Home | 1 | FC100A1029 | 3TPR7 |
| 20x20x5 | Honeywell 203721 | Honeywell Home | 1 | FC100A1011 | 3TMZ6 |
| MERV 11 | | | | | |
| 16x20x3 | Honeywell FC40R1052 | Air Handler | 2 | 36PR84 | 36PR84 |
| | Honeywell CF200A1620 | Air Handler | 2 | 36PR92 | 36PR92 |
| 16x20x5 | Honeywell CF200A1620, FC100A1003, FC200E1003, POPUP1620 | Bestair Pro | 2 | 5-1620-11-2 | 35N242 |
| | Honeywell FC35A1035 | Air Handler | 2 | 36PR88 | 36PR88 |
| 16x25x3 | Trion Air Bear Cub, Lennox, GeneralAire, Skuttle, Source 1/York, MAC 259112-101, 255649-101 | Bestair Pro | 2 | AB-31625-11-2 | 35N237 |
| | Trion Air Bear Cub, Lennox, GeneralAire, Skuttle, Source 1/York, MAC 259112-101, 255649-101 | Air Handler | 2 | 36PR85 | 36PR85 |
| 16x25x5 | Goodman Amana, York M11056 | Bestair Pro | 2 | G5-1625-11-2 | 35N249 |
| | Honeywell CF100A1009, CF100A1041, CF200A1008, FC100A1029, FC200E1029, POPUP1625, CF100A1041, 203719, F35/35R FC35A1001, F100/150 FC100A1026/1029, F200 FC200E1029, 203719 | Bestair Pro | 2 | 5-1625-11-2 | 35N244 |
| | Honeywell CF200A1008 | Air Handler | 2 | 36PR93 | 36PR93 |
| | Honeywell F100F1004, F100B1008, F150E1000, F100F2028 | Honeywell Home | 1 | POPUP1625 | 3PT11 |
| | Honeywell FC35A1001 | Bestair Pro | 2 | NR5-1625-11-2B | 52XR42 |
| | Trion Air Bear 455602-625 | Air Handler | 2 | 36PR89 | 36PR89 |
| 16x27x6 | Trion Air Bear Cub, Lennox, GeneralAire, Skuttle, Source 1/York, MAC 259112-105, 255649-105 | Bestair Pro | 2 | AB-51625-11-2 | 35N235 |
| | Aprilaire Space Gard, Lennox 401 | Bestair Pro | 2 | A401-SG4-BOX-11R | 35N240 |
| 16x28x6 | Aprilaire Space Gard, Lennox 401 | Bestair Pro | 2 | NRSG411-11-2B | 52XR46 |
| 20x20x3 | Carrier GAPCCCAR2020 | Honeywell Home | 1 | POPUP2400 | 3PT15 |
| | Goodman, Amana, York M21056 | Air Handler | 2 | 36PR86 | 36PR86 |
| 20x20x5 | Honeywell CF200A1024 | Bestair Pro | 2 | G5-2020-11-2 | 35N250 |
| | Honeywell CF200A1024, FC100A1011, FC200E1011, POPUP2020 | Air Handler | 2 | 36PR94 | 36PR94 |
| | Honeywell F100F1004, F100B1008, F150E1000, F100F2028 | Bestair Pro | 2 | 5-2020-11-2 | 35N243 |
| | Honeywell FC35A1043 | Honeywell | 1 | POPUP2020 | 278V54 |
| 20x25x3 | Trion Air Bear 455602-725 | Bestair Pro | 2 | NR5-2020-11-2B | 52XR43 |
| | Trion Air Bear 455602-925 | Air Handler | 2 | 36PR90 | 36PR90 |
| 20x25x4 | Aprilaire Space Gard, Lennox 210/213 | Air Handler | 2 | 36PR87 | 36PR87 |
| | Honeywell F100F2010, F150E1034, F100B1032, F100F2038 | Bestair Pro | 2 | NRSG211-11-2B | 52XR45 |
| 20x25x5 | Goodman, Amana, York M81056 | Honeywell Home | 1 | FC100A1037 | 3TPR8 |
| | Honeywell 203720, F35/35R FC35A1027, F100/150 FC100A1037, F200 FC200E1037, CF100A1025, CF100A1058, FC100A1037, FC200E1037, POPUP2025 | Bestair Pro | 2 | G5-2025-11-2 | 35N251 |
| | Honeywell F100F1004, F100B1008, F150E1000, F100F2028 | Bestair Pro | 2 | 5-2025-11-2 | 35N245 |
| | Honeywell FC100A1037 | Honeywell Home | 1 | POPUP2025 | 3TPT3 |
| | Honeywell FC35A1050 | Air Handler | 2 | 36PR95 | 36PR95 |
| | Trion Air Bear 455602-025 | Bestair Pro | 2 | NR5-2025-11-2B | 52XR44 |
| 20x25x6 | Trion Air Bear Cub, Lennox, GeneralAire, Skuttle, Source 1/York, Braeburn 259112-102, 255649-102 | Air Handler | 2 | 36PT03 | 36PT03 |
| | Trion Air Bear Cub, Lennox, GeneralAire, Skuttle, Source 1/York, Braeburn 259112-102, 255649-102 | Bestair Pro | 2 | AB-52025-11-2 | 35N236 |
| 20x25x6 | Aprilaire 201 | Air Handler | 2 | 36PR91 | 36PR91 |
| | Aprilaire Space Gard, Lennox 201 | Air Handler | 2 | 36PT10 | 36PT10 |
| 21x25x6 | Aprilaire Space Gard, Lennox 201 | Bestair Pro | 2 | A201-SGM-BOX-11R | 35N239 |
| | Honeywell F100F1004, F100B1008, F150E1000, F100F2028 | Bestair Pro | 2 | SGMPR-2 | 35N241 |
| 28x16x6 | Aprilaire Space Gard, Lennox 401 | Honeywell Home | 1 | POPUP2200 | 3PT14 |
| | Aprilaire Space Gard, Lennox 401 | Bestair Pro | 2 | SG4PR-2 | 35N238 |
| MERV 13 | | | | | |
| 16x20x5 | Honeywell CF200A1620, FC100A1003, FC200E1003, POPUP1620 | Bestair Pro | 2 | 5-1620-13-2 | 35N259 |
| | Honeywell, Lennox CF100A1009, CF100A1041, CF200A1008, FC100A1029, FC200E1029, POPUP1625, CF100A1041, 203719, F35/35R FC35A1001, F100/150 FC100A1026/1029, F200 FC200E1029, 203719 | Bestair Pro | 2 | 5-1625-13-2 | 35N261 |
| 16x25x5 | Trion Air Bear Cub, Lennox, GeneralAire, Skuttle, Source 1/York, MAC 259112-105, 255649-105 | Bestair Pro | 2 | AB-51625-13-2 | 35N252 |
| | Honeywell CF200A1024, FC100A1011, FC200E1011, POPUP2020 | Bestair Pro | 2 | 5-2020-13-2 | 35N260 |
| 20x20x5 | Lennox HCF20-10, HCF20-10, HCF20-16 | Bestair Pro | 2 | LN2025-13C | 35N263 |
| | Carrier EXPXXFIL0020, EXPXXUNV0020, EXPXXFIL0320, EXPXXUNV0320 | Bestair Pro | 2 | CB2025-13C | 35N255 |
| 20x25x5 | Honeywell 203720, F35/35R FC35A1027, F100/150 FC100A1037, F200 FC200E1037, CF100A1025, CF100A1058, FC100A1037, FC200E1037, POPUP2025 | Bestair Pro | 2 | 5-2025-13-2 | 35N262 |
| | Trion Air Bear Cub, Lennox, GeneralAire, Skuttle, Source 1/York 259112-102, 255649-102 | Bestair Pro | 2 | AB-52025-13-2 | 35N253 |
| 24x25x5 | Carrier EXPXXFIL0324, EXPXXUNV0324, EXPXXFIL0024, EXPXXUNV024 | Bestair Pro | 2 | CB2425-13R-2 | 35N256 |
| | 25x16x5 | Carrier EXPXXFIL0016, EXPXXUNV0016, EXPXXFIL0316, EXPXXUNV0316 | Bestair Pro | 2 | CB1625-13C |

* Refill media only.